



Nameplate Installation Guide

Materials Needed:

- Masking tape
- Windex/glass cleaner
- Rubbing alcohol
- Clean microfiber towel

IMPORTANT WINTER NOTE: To ensure proper adhesion of mastic, the glass area should be **at least 65 degrees**. After cleaning the window, we recommend using a heat gun or hair dryer to warm the glass if needed.

- Nameplates have the mounting bolts installed correctly

Step 1: Clean the two stud locations with Windex or glass cleaner first, then with rubbing alcohol. Be sure no dirt, wax, or silicon material remains on the glass.

Step 2: Following the cleaning of the window, peel the film from the two sided tape on the mounting bolts.

Step 3: Place one of the mounting bolts firmly on the window. Doing so will allow you to pivot the nameplate on this bolt.

Step 4: Make the nameplate level and press the other mounting bolt firmly to the glass. The adhesive will continue to adhere for the next several hours.

If you remove the nameplates the next day, be sure to store them somewhere to avoid damage.

Important Notes

- Be sure to check the acorn nuts periodically to ensure they don't come loose. **Never tighten acorn nuts more than finger tight.**
- Do NOT run the vehicle through an automatic car wash without removing nameplates first.
- Should a stud ever come loose from the glass, do **NOT** operate the vehicle until the bar is removed.

The bars can be removed in a few days by turning the acorn nuts counter clockwise. For a finished look and to possibly prevent loss of parts, replace formed washers and acorn nuts. **DO NOT OVER TIGHTEN.** Reverse the procedure to reinstall nameplates.