

Casket Roller Replacement Instructions

Tools Needed:

☐ Towel

Step 6:

Step 7:

Step 8:

Step 9:

□ 3/8 Wrench This instruction sheet provides step-by-step guidance on how to replace a roller in our casket roller assembly. Want visual instructions? Check out our instructional video by visiting our YouTube channel or website. Step 1: Remove the frame housing from the floor of your vehicle Step 2: Flip the housing over Step 3: Locate the four bolts that hold the roller into the frame Step 4: Remove the bolts and brackets, set aside Step 5: Remove the roller with the rod, and then the rod from the roller

Slide rod into new roller and place new end caps on

Place back into frame, ensuring that it is centered

Reinstall the roller back into the floor and done!

Have a question or comment? Email us at gburnsllc@gmail.com or call us at 937-210-4805.

Reinstall brackets and the four bolts back into the frame, tighten bolts

Please send a photo of your Landau Bars, Nameplate, or any other G. Burns product to gburnsllc@gmail.com

Please review us at: https://g.page/g-burns-llc/review?rc